

**HW**



**MAN**

D 125 n 6200 - 10700  
D 140 n 5500 - 9500

D	B	d	Z	V	COD.
125	9	40	2	4	K410120940
125	10	40	2	4	K410121040
125	12.5	40	2	4	K410121240
125	17	40	2	2	K410121740
125	20	40	2	2	K410122040
140	12.5	40	2	4	K410141240
140	20	40	2	2	K410142040



Ricambi / Spare parts / Rechanges / Repuestos / Ersatzteile



	COD.	COD.	COD.	COD.	COD.	COD.	COD.	COD.
B = 9	0480030014	0480050007	0480500700	048060A000	0480700512	048074A507	0480782500	048078T200
B = 10	0480030014	0480050009	0480500700	048060A000	0480700512	048074A507	0480782500	048078T200
B = 12.5	0480030014	0480050012	0480501000	048060B000	0480700512	048074A510	0480782500	048078T200
B = 17	0480030014	0480050017	0480501300	048060C000	0480700612	048074A510	0480783000	048078T200
B = 20	0480030014	0480050020	0480501800	048060C000	0480700612	048074A510	0480783000	048078T200

Grooving bed cutter heads.

Cabezales para ranuras guía.

Porte - outils pour rainures de guidage.

Nutenbett - Messerköpfe.